



# Dell Optiplex 745 Ultra Small Form Factor Hard Drive Replacement

Upgrade or replace your hard disk.

Written By: donnayon



## INTRODUCTION


Failed hard drive? Need more storage? This guide will walk you through removal of your HDD.

## Step 1 — Side Panel



- ⚠ Make sure to shut down the computer! you can do this by going to the start menu and clicking shutdown.
- ⚠ Ensure all cables, speakers and other devices are unplugged and turned off before opening the computer case.

## Step 2



- Lay the computer on its side; you will see a blue knob. Turn said knob 90 degrees counter clockwise.



### Step 3



- Slide the panel case forward about 1/2 inch while knob is turned.
- Lift panel case off computer.

### Step 4 — Hard Drive



- Remove power and data cables
- ☑ Ground yourself before removing any internal components.

## Step 5



- Locate blue tabs as shown to the left and right of the hard disk drive
- Squeeze tabs and slide hard disk drive towards you, then lift up on the drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-11-28 04:56:01 PM.